

# qonvolv

KA002A
Rib Cuff Attaching Machine





Sewing Guide Design





Rib Cuff Before Attaching



Sleeve Before Attaching

- Simplified operation only requiring operators to place cuff and sleeve panel according to sewing guide positioning. Eliminating training for traditional manual operations.
- Digitalized control for different styles and sizes with memory function. Enabling quick changeover through simple touch screen selection.
- Dedicated fabric edges rolling prevention device
   eliminating the need for manual handling during sewing.



Finished Sleeve after Attaching Rib Cuff

## **APPLICATIONS**

### **Styles**

Rib Cuffs for Long Sleeve Shirts and Pants

### Size and Dimensions

Cuff Height: **40-75mm** Cuff Width: **>=65mm** 

### **Fabrications**

Double Face, French Terry, Jersey

# **SPECIFICATIONS**



Sewing Machine Head **PEGASUS ETX5114** 



Dimensions (mm) L: 1,020 x W: 695 x H: 1,200



Stitch Type
Overlock Stitch (#514)



Power (W) **2,000** 



Compressed Air Requirement (Mpa) **0.5** 



Power Supply (V) AC 220 (50Hz)



Needle **DCx1** 



Max. Sewing Speed (rpm) **3.000** 



Changeover Time (m)



Weight (kg) 250



**Quaternion Hong Kong Limited** 13/F, Harbour Center, 25 Harbour Road Wanchai, Hong Kong

+852 2811 8077 cs@qonvolv.com www.qonvolv.com

